



p. 51 (picture on top of page)

Cutout:



Picture text: Whenever the turntable moves, a mechanical device drives the man to turn the crank.

(This should rather say:

"Whenever the man turns the crank, a mechanical drive causes the turntable to move" ;-) ...)